




馈管内插芯 INNER SUPPORT



名称	型号	规格(英寸)	使用频率 (MHz)
Name	Model	Specification(inch)	Frequency (MHz)
馈管内插芯 INNER SUPPORT	RL078-06	7/8"	DC-880
	RL158-05	1-5/8"	
	RL318-06	3-1/8"	
	RL412-05	4-1/2"	
	RL618-05	6-1/8"	

